

This sign must be posted during Hot Work operations and all guidelines followed during these operations.

Designated Area

Building 2 room 102, 104, & 106

These areas are designated for a small butane torch to heat wires and small metal.

1. All flammables and combustibles must be cleared from the area.
2. No squeeze bottles with flammables on table when doing hot work.
3. Hot Work must be done over the noncombustible table top i.e. metal, aluminum foil etc...
4. You have to be fire extinguisher and Hot Work trained, to utilize this designated hot work area.
5. Thorsten Weber will enforce the above rules, to ensure all guidelines are followed during this operation. If you have questions or concerns about the operation, please contact Thorsten Weber.
6. No hot work allowed when sprinklers are impaired in the area.

The designated Hot Work area must always be free of combustibles and flammables, even when not in use.

Only approved users can utilize this area and the hot work tools. The users include:

Operator name:	Signature: Understand the rules above
Felix Strum	
Bishwanath Gaire	
Daniel Slaughter	
James Cryan	
Rafal Rakowski	
Thorsten Weber is the responsible person	
Eli Champenois	
Travis Wright	

NOTE! THE SHIELDED AREA IS CONSIDERED A DESIGNATED AREA AND A HOT WORK PERMIT IS NOT REQUIRED (NFPA 51B 2009 ed, 3.3.1 & A5.4.2(15)). YOU MUST LIMIT YOUR WORK TO THE STATEMENT ABOVE AND FOLLOW ALL OF THE RULES; OTHERWISE YOU MUST OBTAIN A HOT WORK PERMIT (X6015) PRIOR TO ANY WORK.

You must be authorized by your supervisor (on your JHA) to do this work

A violation of these rules could result in operator removal from the list and possible removal of the designated area.

For questions regarding this designated area: contact the Amie Krigbaum @ X- 5479. This sign is valid through 1/2014